

# HONEY MOISTURE METER (MODEL : GMK-315AC)

## 1. DESCRIPTION OF THE INSTRUMENT



## 2. BEFORE MEASUREMENT

- WITH 'BATTERY REMOVER', TURN LEFT THE LID OF BATTERY COMPARTMENT (BACK SIDE).
- WATCHING +/- POLES CAREFULLY, PLACE BATTERY 9V 1EA IN IT.
- IF 'CAL' SIGN APPEARS ON LCD AND DISAPPEARS, THE INSTRUMENT IS READY TO MEASURE IN NORMAL CONDITION (**AUTOMATIC CALIBRATION**)
- WIPE 'SAMPLE WELL' WITH CLEAN WATER & TISSUE

## 3. MEASUREMENT

- BY USING A 'SAMPLE SPOON', PLACE SOME HONEY SAMPLE ON SAMPLE WELL ENOUGH TO COVER THE PRISM OF THE SAMPLE WELL (# WHEN THE PRISM IS EXPOSED TO THE AIR OR IN CASE OF NO TEST SAMPLE ON THE SAMPLE WELL, 'Err' SIGN APPEARS ON LCD.).
- PLACE 'LIGHT COVER' ON SAMPLE WELL AND PRESS MEASURE BUTTON.
- AFTER (— — —) SIGN FLICKERS THREE TIMES, MEASUREMENT RESULT APPEARS ON LCD FOR ABOUT TWO MINUTES.
- IF THE TEST SAMPLE IS OUT OF THE MEASURING RANGE, 'Err' SIGN APPEARS.

## 4. IMPORTANT

- BEFORE EVERY MEASUREMENT, CLEAN THE SAMPLE WELL WITH WATER & TISSUE.
- WHEN LOW BATTERY SIGN APPEARS, REPLACE THE BATTERY SHORTLY
- AVOID DIRECT RAYS OF LIGHT AND DON'T STORE THE UNIT AT DAMP PLACE.
- IN CASE OF NO USE FOR A LONG TIME, MAKE SURE TO REMOVE THE BATTERY
- WARRANTY PERIOD IS 12 MONTHS AFTER THE DATE OF PURCHASE.
- IN CASE OF WRONG USE, ABUSE OR MISUSE, WARRANTY WILL NOT BE GRANTED,

## ACCESSORIES



Battery remover



Light cover



Sample Spoon



Carrying bag

## G-WON HITECH CO., LTD.

WOOLIM E-BIZ. CENTER 310,  
#170-5, GURO-DONG, GURO-GU,  
SEOUL, KOREA(152-769)  
Tel : 82-2-2108-1646(DIR.)  
Fax : 82-2-2108-1649  
E-MAIL : g-won@g-won.co.kr

## Other Instruments

- |                        |                         |
|------------------------|-------------------------|
| ■ Grain Moisture Meter | ■ Coffee Moisture Meter |
| ■ Wood Moisture Meter  | ■ Tea Moisture Meter    |
| ■ Flour Moisture Meter | ■ Thermo-Hygro Meter    |
| ■ Digital Salt Meter   | ■ Fruit Acidity Meter   |

